



Power- und Trigger-Stecker für Basler Kameras


ace (GigE/USB), MED ace (GigE/USB), beat (Camera Link), racer (Camera Link)

	Stecker Kamera	Stecker Kabel	Geeignete Kabel
Power und Trigger 	HR10A-7R-6PB Hirose, male 6-Pin	HR10A-7P-6S Hirose, female 6-Pin	BAS-ACC-CBL-2000034087 BAS-ACC-CBL-2000034086 BAS-ACC-CBL-2000034088 BAS-ACC-CBL-2000034084 H06S-TO-OPEN_FULL H06S-TO-OPEN_FULL_SKT H06S-TO-OPEN_DS



ace2 (GigE/USB), boost (CoaXPress)

	Stecker Kamera	Stecker Kabel	Geeignete Kabel
Power und Trigger 	M8: IEC 61076-2-104 A-Coding, female, 6-Pin	M8: A-Coding, male, 6-Pin	BAS-ACC-CBL-2200000315 BAS-ACC-CBL-2200000296


ace (Camera Link)

	Stecker Kamera	Stecker Kabel	Geeignete Kabel
Power und Trigger 	M5: 09-3111-86-04 Binder, male, 4-Pin	M5: 79-3108-52-04 Binder, female, 4-Pin	BAS-ACC-CBL-2000031224



blaze

	Stecker Kamera	Stecker Kabel	Geeignete Kabel
Power und Trigger 	M12, 8-pin, female IEC 61076-2-101	M12, 8-pin, male	BAS-ACC-CBL-2200000276
Ethernet 	M12, x-coded, 8-pin, female IEC 61076-2-109	M12, x-coded, 8-pin, male	BAS-ACC-CBL-2200000284

aviator (GigE), pilot (GigE), scout (GigE), ToF

	Stecker Kamera	Stecker Kabel	Geeignete Kabel
<p>Power und Trigger</p> 	<p>HR10A-10R-12P Hirose, male 12-Pin</p>	<p>HR10A-10P-12S Hirose, female 12-Pin</p>	<p>H12S-TO-OPEN_FULL BAS-ACC-CBL-2000034085</p>

aviator (Camera Link), racer (GigE)

	Stecker Kamera	Stecker Kabel	Geeignete Kabel
<p>Power</p> 	<p>HR10A-7R-6PB Hirose, male 6-Pin</p>	<p>HR10A-7P-6S Hirose, female 6-Pin</p>	<p>H06S-TO-OPEN_FULL H06S-TO-OPEN_FULL_SKT H06S-TO-OPEN_DS</p>
<p>Trigger</p> 	<p>HR10A-10R-12P Hirose, male 12-Pin</p>	<p>HR10A-10P-12S Hirose, female 12-Pin</p>	<p>H12S-TO-OPEN_FULL BAS-ACC-CBL-2000034085</p>